


FIG. 5 (PRIOR ART)

651

69



95 TRANSMIT ➤ OFDM ZERO PREAMBLE GENERATOR MUX INSERTION **SIGNAL** SECTION DATA 93 105-103 -CROSS CORRELATION CALCULATOR SYNC. TIMING CALCULATOR SYNC TIMING DETECTOR; **ZERO** PREAMBLE INSERTION GENERATOR SECTION FIG. 991A 99A-101A 97A(PRIOR ART)